

How to use our CT1 Adhesive/Sealant.

As an adhesive

- Ensure that both the reverse of the splashback/upstand are clean, dry and dirt free.
- Apply several lines sparingly to the reverse of the splashback/upstand.
- Push into place and hold the splashback/upstand for approximately 2 minutes.
- Remove any excess CT1 from the visible surfaces of the splashback/upstand immediately using a clean, lint free cloth soaked in white spirit.

As a sealant.

- Run a thin line of CT1 along the join between the splashback/upstand and any other surface.
- Evenly blend the CT1 using a clean, lint free cloth soaked in white spirit.
- Remove any excess CT1 from the visible surfaces of the splashback/upstand immediately using a clean, lint free cloth soaked in white spirit. Approximately 30 minutes – 1 hour after sealing, streaks may appear on the surface of the steel. This should be cleaned as before, with white spirit.
- PLEASE NOTE: **ALWAYS** use a separate cloth for blending and both stages of cleaning.